

SVECIA

Dryer / Trockner



Beuerlein
svectia.de















Beuerlein

SVECIA Siebdruckmaschinen-Service

Tel.: 0049 9383 9020360
Fax: 0049 9383 202217

E-Mail: info@svectia.de
Homepage: www.svectia.de

	Machine unit description Beuerlein Svecia spare parts	Page 01

<p>100 Elektrodiagram/ wiring diagram</p> 	<p>101 Zeitrelay/ time relay</p> 	<p>102 Schütz/ protect.</p> 	<p>103 Motorschutz 0-10 Amp./ motor protect. 0-10 amp</p> 
<p>420 Trocknerband, weiß/ dryer belt, white</p> 	<p>421 Trocknerband UV/ dryer belt UV</p> 	<p>422 TROCKNER / DRYER Spezialband für Bandwalze special tape for belt roller</p> 	<p>115 DC Generator</p> 
<p>120 Kondensator UV/ cap. UV</p> 	<p>121 Kondensator UV/ cap. UV</p> 	<p>122 Kondensator UV/ cap. uv</p> 	<p>108 Relay 3500 VAC/10 AMP mercury switch 3500V AC 10 AMP</p> 
<p>125 Trafo 230/24V</p> 	<p>126 Trafo 400/230 AC</p> 	<p>127 Trockner Trafo UV/ dryer trafo uv</p> 	





	Machine unit description Beuerlein Svecia spare parts	Page 02

<p>145 TRB 05 Bandsteuerung/ TRB 05 belt contrl.</p> 	<p>148 Steuerung GME 1806-A/ controller GME 1806-A</p> 	<p>150 Bandsteuerung 1809 AT/ belt controller 1809 AT</p> 	<p>155 IR Steuerung HPF 4460/ IR controller HPF 4460</p> 
<p>212 Notstopp/ emergency stop</p> 	<p>213 Übertemperatur Schalter/ overload switch</p> 	<p>214 Vakuumdose/ vacuum can</p> 	
<p>216 Bandpoti/ belt poti</p> 	<p>223 UV-Klemmstein/ UV-conector</p> 	<p>219 TROCKNER Klemmleisten/ DRYER connector</p> 	
<p>230 Bandgeschwind. anzeige/ speed display</p> 	<p>231 UV Anzeige/ uv display</p> 	<p>109 Warnhupe/ signal horn</p> 	<p>110 Lüfter/ fan</p> 
<p>233 Thermostatregler/ thermos.</p> 	<p>234 TROCKNER schalter switch</p> 	<p>208 Hauptschalter/ main switch</p> 	

	Machine unit description Beuerlein Svecia spare parts	Page 03

<p>236 IR Quartzstrahler/ IR quartz lamp</p> 	<p>237 IR Strahler/ IR lamp</p> 	<p>238 UV Lampe/ UV lamp</p> 	<p>239 UV Spiegel (ohne Lampe)/ UV mirror (without lamps)</p> 
<p>240 Heizblock/ heating block</p> 	<p>241 Heizschlange Trockner/ heating spiral</p> 	<p>242 Temperaturfühler/ temp. sensor</p> 	<p>243 Bandwalzen Ø 110/70 mm Belt rollers Ø 110/70 mm</p> 
<p>305 Band-Antriebsmotor/ belt drive motor</p> 	<p>318 Winkel Getriebe/ angular gear</p> 		
<p>308 Trockner-Lüftermotor/ dryer fan motor</p> 	<p>309 Trockner Stellmotor/ servo-motor</p> 	<p>310 Lüfterrad/ fan</p> 	<p>311 Lüfterhaube, -gitter/ fan grille</p> 

	Machine unit description Beuerlein Svecia spare parts	Page 04

<p>440 Trockner Luftschl.100\150\200 mm dryer air tube 100\150\200</p> 	<p>600 HV UV Hochspannungskabel/ HV UV cable</p> 	<p>608 Hammerschlag Lack / hammer finish paint</p> 	<p>609 Original Farbe rot\grün\blau\gelb/ paint red\green\blue\yel.</p> 
--	---	---	--

Beuerlein

svecia.de